BELZONA SAFETY GRIP SYSTEM ON STAIRS

CUSTOMER

Manufacturer, UK

APPLICATION DATE

July 2012

APPLICATION SITUATION

Metal stairs leading to a mezzanine floor area.

PROBLEM

A potential slip hazard was identified on the metal stairs.

PRODUCTS

Belzona® 4411 (Granogrip)

SUBSTRATE

Steel

APPLICATION METHOD

Application was carried out in accordance with Belzona Know-How System Leaflet FPA-8. After preparing the area with an MBX Bristle Blaster stripes of Belzona® 4411 red and yellow safety colours incorporating Belzona® 9221 aggregate were applied.

BELZONA FACTS

Belzona® 4411 gave a quick and easy solution to removing a slip hazard from a busy set of stairs. The non-slip properties of the Belzona Grip system are ideal for this dusty environment and safety colours aide in both identifying the step edges and in highlighting the potential hazard.

PICTURES

- 1. Steps before Belzona Application
- 2. Abraded and Masked steps
- 3. Half of steps completed
- 4. Completed application









For more examples of Belzona Know-How In Action, please visit http://khia.belzona.com



BELZONA®
Repair • Protect • Improve