

BELZONA UPGRADES MORTUARY FLOOR

ID: 1636

Industry: Buildings & Structures
Application: CEP-Centrifugal Pumps
Substrate: Concrete
Products: * Belzona® 4131 (Magma Screed) ,
* Belzona® 5231 (SG Laminate) ,

Customer Location: Hospital Mortuary, Glasgow
Application Date: March 2008

Problem

As the floor was regularly washed down, it had caused the floor to become damaged and uneven causing water to gather in certain areas.



Photograph Descriptions

- * Damaged floor ,
- * Examination table base screeded with Belzona® 4131 ,
- * Floor repairs using Belzona® 4131 ,
- * Completed application after application of Belzona® 5231 ,

Application Situation

The customer required the lifting of the existing floor system and repairing the damaged floor areas, followed by an over-coat of a positive grip system.

Application Method

Application was carried out in accordance with Belzona Know-How System Leaflets FPA-1 & 8. The Belzona® 4131 was first applied for the repairs to the bases of examination tables, and following this, a dark grey Belzona® 5231 with 15% grey aggregate was applied to give the positive traction system the customer required.

Belzona Facts

The whole application was carried out over one weekend. The low odour, solvent free Belzona products did not impact on the normal activities of the hospital. The Belzona system has provided the hospital with a hygienic, safe and hard wearing floor in the

For more examples of Belzona Know - How In Action, please visit <https://khia.belzona.com>

ISO 9001:2015
FS 695214
ISO 14001:2015
EMS 695213

Belzona products are
manufactured under an ISO
9000 Registered Quality
Management System.

www.belzona.com


BELZONA
Repair • Protect • Improve

mortuary.

For more examples of Belzona Know - How In Action, please visit <https://khia.belzona.com>

ISO 9001:2015
FS 695214
ISO 14001:2015
EMS 695213

Belzona products are
manufactured under an ISO
9000 Registered Quality
Management System.

www.belzona.com



Copyright © Belzona International Limited 2024