

## BELZONA® 4000 SERIES FLOOR COATING FOR A STERILIZING ROOM

### CUSTOMER

Medical Sanitizers - Minnesota U.S.A.

### APPLICATION DATE

March 2002

### APPLICATION SITUATION

Floor in a sanitizer room - 100°F at 80% humidity.

### PROBLEM

Floor was spalled, cracked and therefore non-compliant with sanitary requirements.

### PRODUCTS

Belzona® 4151 (Magma-Quartz Resins)

### SUBSTRATE

Concrete

### APPLICATION METHOD

The application was carried out in accordance with a modified version of Belzona Know-How System Leaflet FPA-3. Shot-blasted floor, followed by thorough cleaning. Roller/brush application of product in a slurry-grade.

### BELZONA FACTS

This customer had put the repair out for bid. The Belzona Solution was over seven times more expensive than the other bids received. Because of the aggressive environment and heavy fork lift traffic, only the Belzona System provided the protection required. Tenacity and great care taken in understanding and appreciating the customer's problem led them to believe in the Belzona Solution.

### PICTURES

1. Final steps of surface preparation
2. In progress
3. Job complete



For more examples of *Belzona Know-How In Action*, please visit <http://khia.belzona.com>



Belzona products are manufactured under an ISO 9000 Registered Quality Management System.

UK • USA • Canada • China  
[www.belzona.com](http://www.belzona.com)

