

BELZONA SAVES A LARGE HOT WATER TANK AT A MEDICAL FACILITY

CUSTOMER

Florida, USA

APPLICATION DATE

May, 2017

APPLICATION SITUATION

A large hot water tank, 198 F, used for bath water at a medical facility.

PROBLEM

The original tank was very rusted and the original coating was mostly worn off. They didn't even know if the tank could be saved but were willing to try a new coating system. This facility has many residents and they were afraid the tank would fail and there would not be any money budgeted to get a new tank as quickly as they would need it. This was the only tank they had for this purpose.

PRODUCTS

Belzona 5892

SUBSTRATE

Carbon steel

APPLICATION METHOD

The tank was grit blasted with Black Beauty to Belzona's standards. Then two coats of the 5892 were applied. Belzona 5892 was chosen because it could withstand high temperature and could be put back into service quickly. The application was done in accordance with a modified version of Belzona System Leaflet TCC-5.

BELZONA FACTS

Belzona was chosen because it could withstand high temperature under submersion. There was no money in the budget for a new tank and the current situation was not good for the residents.

PICTURES

1. Rim before Belzona restoration.
2. Inside tank before restoration.
3. Rim after restoration.
4. Inside tank during final coat.



For more examples of *Belzona Know-How In Action*, please visit <http://khia.belzona.com>



Belzona products are
manufactured under an ISO
9000 Registered Quality
Management System.

UK • USA • Canada • Thailand
www.belzona.com


BELZONA
Repair • Protect • Improve