

# REPAIR AND PROTECTION OF HOSPITAL LAUNDRY FLOOR WITH BELZONA

ID: 1523

Industry: Buildings & Structures  
Application: FPA-Floor Problem Areas  
Substrate: Concrete  
Products: \* Belzona® 4131 (Magma-Screed) Belzona® 5231 (SG Laminate) ,

Customer Location: Hospital, Scotland  
Application Date: Oct/ Nov 2009

## Problem

The laundry floor of this hospital was not level and water was gathering in the middle of the floor. They needed the floor to be re-levelled so that water ran to the drains. The floor also had to be safe from accidents.



## Photograph Descriptions

\* Uneven, damaged laundry floor Application of Belzona® 4131 Application of Belzona® 4131 Completed application ,

## Application Situation

Uneven laundry floor of hospital

## Application Method

Application was carried out in accordance with Belzona Know-How System Leaflet FPA-1. Existing floor was cut out to create a fall and then screeded over with Belzona® 4131. This was then overcoated with Belzona® 5231.

## Belzona Facts

The use of Belzona® 4131 allowed falls to be created with minimum disruption to hospital operations. the Belzona® 5231 provided a safe surface for operatives in the laundry. The hospital are now currently looking at improving the safety throughout the building utilising Belzona solutions.

For more examples of Belzona Know - How In Action, please visit <https://khia.belzona.com>

ISO 9001:2015  
FS 695214  
ISO 14001:2015  
EMS 695213

Belzona products are  
manufactured under an ISO  
9000 Registered Quality  
Management System.

[www.belzona.com](http://www.belzona.com)

  
**BELZONA®**  
Repair • Protect • Improve

Copyright © Belzona International Limited 2024