

BELZONA PROVIDES SAVINGS BY SEALING FLOOR

ID: 5349

Industry: Buildings & Structures
Application: FPA-Floor Problem Areas
Substrate: Urethane
Products: * Belzona 2221 (MP Fluid Elastomer) ,
* Belzona 2911 (Elastomer QD Conditioner) ,
* Belzona 9341 (Reinforcing Sheet) ,

Customer Location: WA, USA
Application Date: 1992

Problem

The seams on the floor in the large animal surgery room had split open, allowing bacteria to flourish underneath. The floor had to be sealed.



Photograph Descriptions

- * Drying the floor after cleaning ,
- * Abrading the surface ,
- * Applying Belzona 2221 over the seams ,
- * Completed application ,

Application Situation

Large animal surgery room.

Application Method

The floor was cleaned and disinfected, and then allowed to dry. A roughing tool was used to abrade the surface. Belzona 2911 was applied and allowed to cure. The area was masked off and Belzona 2221 was brushed on with Belzona 9341 to bridge the seam. The application was carried out in accordance with a modified version of Belzona Know-How System Leaflet FPA-6.

For more examples of Belzona Know - How In Action, please visit <https://khia.belzona.com>

ISO 9001:2015
FS 695214
ISO 14001:2015
EMS 695213

Belzona products are
manufactured under an ISO
9000 Registered Quality
Management System.

www.belzona.com

**BELZONA**
Repair • Protect • Improve

Belzona Facts

Belzona solved the problem in a very cost-effective manner. The only alternative solution was a complete replacement of the flooring, which was deemed too expensive.

For more examples of Belzona Know - How In Action, please visit <https://khia.belzona.com>

ISO 9001:2015
FS 695214
ISO 14001:2015
EMS 695213

Belzona products are
manufactured under an ISO
9000 Registered Quality
Management System.

www.belzona.com

