

BELZONA REFURBISHES WALKWAYS

ID: 6178

Industry: Buildings & Structures

Customer Location: Medical Research Centre, Melbourne, Australia

Application: FPA-Floor Problem Areas

Application Date: November 2015

Substrate: Coated concrete

Products: * Belzona 5231 (SG Laminate),

Problem

The existing coating had started to break down creating both a trip hazard and a cleanliness issue for the facility.



Photograph Descriptions

* 1. Floor prepared and masking complete 2. First coat underway 3. First coat almost complete 4. Close up of coating around drain

Application Situation

Walkways between laboratories and holding cells at a medical research centre

Application Method

Application was carried out in accordance with Belzona System Leaflet FPA-8. The application was carried out over night. The coating was also applied partially up the walls to aid with cleaning of the floors.

Belzona Facts

The Belzona SG Laminate was chosen due to its solvent free nature and fast curing ability that allowed 2 coats to be applied in the short application window. The prime consideration was its ability to be applied to and bond onto the minimally prepared surface of the existing coating as mechanical preparation methods of any kind were prohibited.

For more examples of Belzona Know - How In Action, please visit <https://khia.belzona.com>

ISO 9001:2015

FS 695214

ISO 14001:2015

EMS 695213

Belzona products are
manufactured under an ISO
9000 Registered Quality
Management System.

www.belzona.com


BELZONA
Repair • Protect • Improve