

BELZONA BRIGHTENS UP HOSPITAL LAUNDRY FLOOR

ID: 1205

Industry: Buildings & Structures
Application: FPA-Floor Problem Areas
Substrate: Concrete
Products: Belzona® 5231 (SG Laminate)

Customer Location: Medical Center, Anniston, Alabama USA
Application Date: December 2007

Problem

The coating that was currently on the floor was worn and causing slip hazards for the employees.



Photograph Descriptions

* Floor prior to being prepared , * Floor after being abraded , * Belzona® 5231 being applied , * Completed floor ,

Application Situation

Hospital was looking to replace coating on laundry room floor.

Application Method

Application was carried out using a modified Belzona Know-How System Leaflet FPA-3. The concrete was abraded to remove the existing coating and profile the concrete. Areas masked off and Belzona® 5231 Red and Gray used for demarcation.

Belzona Facts

This customer had to have the application done and ready for foot traffic in one weekend. Because of the quick cure times Belzona® 5231 was a perfect fix. One year later the application still looks great.

For more examples of Belzona Know - How In Action, please visit <https://khia.belzona.com>

ISO 9001:2015
FS 695214
ISO 14001:2015
EMS 695213

Belzona products are
manufactured under an ISO
9000 Registered Quality
Management System.

www.belzona.com


BELZONA®
Repair • Protect • Improve